



**IF THIS OVEN IS NOT PROPERLY INSTALLED A FIRE MAY RESULT. TO REDUCE THE RISK OF FIRE, FOLLOW THESE INSTALLATION INSTRUCTIONS. A MAJOR CAUSE OF OVEN RELATED FIRES IS FAILURE TO MAINTAIN REQUIRED CLEARANCES (AIR SPACES) TO COMBUSTIBLE MATERIALS. IT IS OF THE UTMOST IMPORTANCE THAT THIS OVEN BE INSTALLED ONLY IN ACCORDANCE WITH THESE INSTRUCTIONS.**

### CLEARANCES

- a. The Wood Stone Bistro oven must have a **minimum 1-inch clearance to combustibles from all sides, 6-inch clearance to combustibles from the top, and 6-inch clearance from the exhaust transition and flue collar.** If building a facade that will contact the oven, use completely non-combustible materials. Any facade wall built above or 6 inches to either side of the doorway must be of non-combustible construction. **Please note that standard drywall (or sheet rock) is considered a limited combustible.** Any walls perpendicular to the front of the oven in the area 30 inches to either side of the doorway and 36 inches in front of the oven should have a non-combustible surface.
- b. This oven should be installed on a non-combustible floor surface. The non-combustible floor surface must extend 36-inches in front of and 30-inches to either side of the oven doorway.

