

INSTALLATION CLEARANCES -- FIRE DECKS 6045 & 8645

TO REDUCE THE RISK OF FIRE, FOLLOW THESE INSTALLATION INSTRUCTIONS. A MAJOR CAUSE OF OVEN RELATED FIRES IS FAILURE TO MAINTAIN REQUIRED CLEARANCES (AIR SPACES) TO COMBUSTIBLE MATERIALS. IT IS OF UTMOST IMPORTANCE THAT THIS OVEN BE INSTALLED ONLY IN ACCORDANCE WITH THESE INSTRUCTIONS.



WARNING: Installation and servicing of this product could expose you to glasswool/ceramic fibers as well as Calcium Silicate dust. **ALWAYS WEAR RESPIRATORY AND EYE PROTECTION WHEN INSTALLING OR SERVICING THIS APPLIANCE.** Please read this entire manual before you install the oven. Failure to follow instructions may result in property damage, bodily injury or even death. Contact your local building or fire officials about restrictions and installation inspection in your area.

WARNING: DO NOT PACK THE REQUIRED AIR SPACE WITH INSULATION OR OTHER MATERIALS.

- a. The Wood Stone Fire Deck oven must have a **minimum 1-inch clearance to combustibles from all sides, and 24-inch clearance to combustibles from the top.** If building materials will contact the oven, they must be completely non-combustible. Please note that standard dry-wall (or sheet rock) is considered a combustible. When non-combustible building materials contact the body of the oven, the respective clearances are transferred to those non-combustibles.
- b. Any facade above and/or 6 inches to either side of the oven doorway, must be constructed of non-combustible building materials.
- c. Install this oven only on a non-combustible floor surface. The non-combustible floor surface should extend 36 inches out in front of the oven, and extend 30 inches to either side of the oven doorway.

